


Video Presentation:




2021-8-3

Fill the special ice pack with water and freeze it. You can also use bottles of any size. By changing the size, you change cooling intensity and duration. Since water expands when freezing, do not fill the containers completely.




Maximum Level




Always empty after use

Slide out, flip and insert the extension if you want to use taller containers





Remove the cap to drain the condensate. Do not tilt Yuki before draining the condensate



How to Clean Yuki



How to Recycle Yuki



Do not turn on the fan when disassembled  
Not suitable for children under the age of 6

Do not flip  
Operating Temperature 5 - 45°



日本語



中文



اللغة العربية



Русский



Italiano



Français



Deutsche



Español



Português



한국어



हिंदी



Bahasa Melayu

